



# Jøtul F 200 HE+



F 200 Short legs



Hole in the floor for external air Ø80

Min. distance to ceiling and furniture



Min. measurements floor plate  
X/Y = According to national laws and regulations

Min. distance to combustible wall



Combustible wall  
Firewall (See chapter 3 in the manual)

# Jøtul F 200 HE+

Min. distance to combustibile wall protected by approved firewall

